


Service manual


15 litres
262 x 460 x 188 mm

3097A


TO OPEN L.S. BOX



3152A



2351 A



2352 A

-LS-



LS401	4 Ω	4822 240 70003
LS402	4 Ω	4822 240 60047

-S-




S426	0,8 mH	4822 152 20481
S427	0,35 mH	4822 157 50595

-C-



C726	12 μ F	4822 124 40076
------	------------	----------------



31490

1	LS401	4 Ω	4822 240 70003
2	LS402	4 Ω	4822 240 60047
3			4822 462 70531
4			4822 426 60055
5			4822 264 30041