



ZF-468/473 kHz

Schalter	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	
Fus 1																												
Mitten																												
Lang																												
T.A																												

